DJI SDR Transmission 2 相机兼容列表

DJI SDR Transmission 2 Camera Compatibility List

品牌 Brand	型号 Model	图传监看（4K） Video Transmission Monitoring (4K)	图传监看（1080p/1080i） Video Transmission Monitoring (1080p/1080i)	相机控制 Camera Control (PTP)	相机镜像控制 Camera Mirroring Control (CEC)
索尼 Sony	A9 III	√	√	√	
	A7C R	√	√	√	√
	A7C	√	√	√	
	A7C II	√	√	√	√
	A7R III	√	√	√	√
	A7R IV	√	√	√	√
	A7R V	√	√	√	√
	A7 III	√	√	√	
	A7 IV	√	√	√	
	A7S III	√	√	√	
	A1 II	√	√	√	
	A1	√	√	√	
	ZV-E1	√	√	√	
	ZV-1 II	√	√	√	√
	ZV-E10 II	√	√	√	√
	ZV-E10	√	√	√	
	A6400	√	√	√	√
	A6500	√	√	√	

品牌 Brand	型号 Model	图传监看（4K） Video Transmission Monitoring (4K)	图传监看（1080p/1080i） Video Transmission Monitoring (1080p/1080i)	相机控制 Camera Control (PTP)	相机镜像控制 Camera Mirroring Control (CEC)
	A6700	√	√	√	√
	FX3	√	√	√	√
	FX30	√	√	√	
	FX6	√	√		
尼康 Nikon	Z5	√	√	√	
	Z5 II	√	√	√	
	Z6	√	√	√	
	Z6 II	√	√	√	
	Z6 III	√	√	√	
	Z7 II	√	√		
	Z8	√	√	√	
	Z9	√	√	√	
	Z30	√	√	√	
	Z50	√	√	√	
	Zfc	√	√	√	
	Zf	√	√	√	
	D850	√	√	√	
佳能 Canon	EOS R1	√	√	√	
	EOS R3	√	√	√	
	EOS R5	√	√	√	
	EOS R5 C	√	√		
	EOS R5 Mark II	√	√	√	
	EOS R6	√	√	√	

品牌 Brand	型号 Model	图传监看（4K） Video Transmission Monitoring (4K)	图传监看（1080p/1080i） Video Transmission Monitoring (1080p/1080i)	相机控制 Camera Control (PTP)	相机镜像控制 Camera Mirroring Control (CEC)
	EOS R6 Mark II		√	√	
	EOS R7		√	√	
	EOS R8	√	√	√	
	EOS R10	√	√	√	
	EOS R50	√	√	√	
	EOS RP	√	√	√	
	EOS 5D Mark IV		√	√	
	EOS 5DS R		√	√	
	EOS-1D X Mark II	√	√	√	
松下 Panasonic	LUMIX S5 II	√	√	√	
	LUMIX S5 IIX	√	√	√	
	LUMIX S9	√	√	√	
	LUMIX S1H	√	√		
	LUMIX S1 II E			√	
	LUMIX S1 II	√	√	√	
	LUMIX GH5S	√	√	√	
	LUMIX GH6	√	√	√	
富士 Fujifilm	X-T3	√	√	√	
	X-T4	√	√	√	
	X-T5	√	√	√	
	X-H2S	√	√	√	
	X-T30	√	√		

品牌 Brand	型号 Model	图传监看（4K） Video Transmission Monitoring (4K)	图传监看（1080p/1080i） Video Transmission Monitoring (1080p/1080i)	相机控制 Camera Control (PTP)	相机镜像控制 Camera Mirroring Control (CEC)
	X-T30 II	√	√		
	X-S10	√	√	√	
	X-S20	√	√	√	
	GFX100 II	√	√	√	

- 相机控制需要相机控制线连接相机和图传发射器，部分相机需要修改 USB 选项为电脑遥控或 PTP。
- 相机镜像控制需要 HDMI 线连接相机和图传发射器，部分相机需要开启 HDMI 信息显示功能。
- The camera control function is supported only when the camera and the video transmitter are connected using a camera control cable. For some camera models, the USB option needs to be set to PC Remote or PTP.
- The camera mirroring control function is supported only when the camera and the video transmitter are connected using an HDMI cable. For some camera models, the HDMI info display function needs to be enabled.